



Index

A

- assistance
 - technical, 10-1
 - telephone numbers, 10-7
 - warranty repair or credit, 10-4
- AutoTech service, 10-2

C

- calling Dell, 10-7
- cautions, v, xvii
- cooling shroud, removing and replacing
 - PowerEdge 1300, 8-12

D

- Dell Diagnostics
 - Device Groups menu, 5-3
 - features, 5-1
 - using, 5-3
- device options, 5-4
- diagnosing problems, 10-1
- diagnostics
 - device group options, 5-3
 - Device Groups Menu, 5-3
 - devices options, 5-4
 - error messages, 5-5
 - parameter options, 5-4

- diagnostics (*continued*)
 - starting, 5-2
 - using, 5-1, 5-3

- Diagnostics Checklist, 10-6
- diagnostics. *See* Dell Diagnostics
- drives
 - formatting, 9-15
 - partitioning, 9-15

E

- EIDE hard-disk drives
 - addressing, 9-10
 - formatting, 9-15
 - installing, 9-10
 - partitioning, 9-15
- electrostatic discharge. *See* ESD
- ESD, xi

F

- fixing problems, 10-1
- formatting
 - EIDE hard-disk drives, 9-15

G

- getting help, 10-1

H

help tools
 AutoTech service, 10-2
 Internet, 10-2
 TechFax service, 10-3
high-level formatting, 9-15

I

Internet help tools, 10-2

L

logical formatting, 9-15

M

messages
 diagnostic error, 5-5

N

notational conventions, v, xvii
notes, v, xvii

P

parameter options, 5-4
partitioning
 EIDE hard-disk drives, 9-15
physical formatting, 9-15
problems
 help tools, 10-1
 with your order, 10-3
product information, 10-4

R

returns, 10-4

S

safety instructions
 for preventing ESD, xi
 health considerations, xii
service, 10-1
starting diagnostics, 5-2
support
 technical, 10-1

T

TechFax service, 10-3
technical assistance
 obtaining, 10-1
 warranty repair or credit, 10-4
troubleshooting
 Diagnostics Checklist, 10-6
 Internet tools, 10-2

W

warnings, v, xvii
warranty repair or credit, 10-4
World Wide Web help tools, 10-2