



# Index

## A

- asset tag number
  - assigning, 2-4
  - deleting, 2-4
- asset tag utility, 2-4
  - using, 2-4

## B

- backup devices, C-1

## C

- cautions, v
- cleaning
  - accessories, C-2
  - drives, C-3
  - internal components, C-2
  - solutions, C-3
  - system exterior, C-3
  - tools, C-2
- computer
  - cleaning, C-3

## D

- data
  - backups, C-1
  - loss and recovery, C-2
  - recovery tools, C-2
- Dell OpenManage Server Assistant CD
  - navigating, 2-2
  - Server Setup mode, 2-2
  - service mode, 2-2
  - setup mode, 2-1
  - starting, 2-1
  - utility partition, 2-3
- diskette drives
  - cleaning, C-3
  - head-cleaning kit, C-3

## E

- electrostatic discharge. *See* ESD
- EMI, C-6
- ESD, xi
- exterior cleaning of system, C-3

## G

- grounding strap, C-3

## **H**

hard-disk drives  
  cleaning, C-3  
  data recovery, C-1

## **K**

keyboard  
  cleaning, C-3

## **M**

monitor  
  cleaning, C-3

## **N**

notational conventions, v  
notes, v

## **P**

power  
  protection devices, C-9  
  surges and spikes, C-8  
power source interruptions  
  preventing, C-8

## **R**

recovering data  
  tools, C-2  
regulatory notices, D-2  
return policy, E-7  
RFI, C-6

## **S**

safety instructions  
  for preventing ESD, xi  
  health considerations, xii  
surge protector  
  preventing power source interruptions,  
  C-9  
system environment  
  altitude, C-5  
  corrosion, C-6  
  dust, C-5  
  EMI and RFI, C-6  
  ESD, C-6  
  humidity, C-5  
  magnetism, C-7  
  power source, C-8  
  shock and vibration, C-7  
  temperature, C-4

## **T**

tape drives  
  backing up data, C-1  
  cleaning, C-3  
tools  
  cleaning, C-2

## **U**

uninterruptible power supply. *See* UPS  
UPS, C-9

## **W**

warnings, v  
warranty information, E-1, E-3, E-5